



Pi Supply



Trezarcoin StakeBox

StakeBox and Trezarcoin have partnered together to bring you the Trezarcoin StakeBox - a device that allows you to stake your Trezarcoin cryptocurrency and make a return on your investment.

Trezarcoin is a Proof-of-Stake cryptocurrency which means you don't require a powerful computer rig to earn rewards. Staking is the process of securing the network with your coin weight, which in turn rewards you with new Trezarcoin.

The stakebox requires little setup allowing you to get up and running in no time at all and includes all the essential accessories. Set it up and start earning crypto rewards* without needing to buy an expensive computer rig.

What's Inside

- Raspberry Pi 3 Model B
- Trezarcoin Case
- 2.5A International Power Supply Unit
- 16GB SD card with Trezarcoin software
- HDMI cable

Raspberry Pi 3 Specifications

- Processor
 - Broadcom BCM2387 chipset
 - 1.2GHz Quad-Core ARM Cortex-A53
 - 802.11 b/g/n Wireless LAN and Bluetooth 4.1 (Bluetooth Classic and LE)
- GPU
 - Dual Core VideoCore IV? Multimedia Co-Processor. Provides Open GL ES 2.0, hardware-accelerated OpenVG, and 1080p30 H.264 high-profile?decode
 - Capable of 1Gpixel/s, 1.5Gtexel/s or 24GFLOPs with texture filtering and?DMA infrastructure
- Memory
 - 1GB LPDDR2
- Operating System
 - Boots from Micro SD card, running a version of the Linux operating system or?Windows 10 IoT
- Dimensions
 - 85 x 56 x 17mm
- Power
 - Micro USB socket 5V1, 2.5A

Learn More

- Getting started with TrezarCoin StakeBox
- How to remotely access your TrezarCoin StakeBox
- How to backup and restore your TrezarCoin wallet
- View all guides
-

