


I²C Interface NEVO+ Series

Accessories

NEVO series PSUs are modular and user configurable power supplies offering unrivalled performance and flexibility. Standard output modules cover voltages from $1.5V_{DC}$ to $58V_{DC}$ and can deliver up to 25A per module. The capability to series and/or parallel outputs in any combination results in a flexible power delivery platform that is suitable for almost all applications.

Output modules 1 to 4 also come with full range analog remote control of both voltage and current as standard and now with the release of the new I²C interface, NEVO series outputs can be easily controlled using low cost microcontrollers.

The I²C interface plugs directly into each output module and provides a standard I²C bus as an alternative to the normal analog controls. The interface connects to J5 on the output module and provides a similar socket for connection to the user application as shown below.



The output voltage and current limit can then be controlled in +/-127 steps that are programmed through the I²C interface. Careful consideration must be given to system grounding as the interface is <u>not</u> isolated and must be referenced to the COM pin on J5. Incorrect system grounding may cause damage to the unit. Adhere to the same precautions as for "Local bias supply" detailed on page 16 of the user manual or contact Vox Power for assistance.

I²C slave address

Each interface can be programmed to any one of four slave addresses via on-board dip switches.

Switch setting (1=ON, 0=OFF, X=Don't care)			Slave Addres	
1	2	3	4	s
0	0	Х	Х	20h
0	1	Х	Х	60h
1	0	Х	Х	A0h
1	1	Х	Х	E0h

Memory Organization		
Memory address	Control function	
F8h	Voltage	
F9h	Current	

Register format							
Sign	MSB						LSB
S	D ₆	D ₅	D4	D3	D ₂	D1	D ₀

S = sign bit (0b) [1= Positive, 0 = Negative]

 $D_X = 7$ bit data (000000b)


() indicates power on default. I²C protocol and timing diagrams are available on request.

Ordering information Order NEVO I²C

Voltage control

Memory address = F8h Adjust range = +/-100% of voltage set with potentiometer Adjust resolution = +/-7 bit (0.4% steps) Power on setting = 0% adjust (eg. Vout = Vset)

Control equations: Vout = Vset*(1-(Data/116.27))	[1]
or Data = 116.27*(1-(Vout/Vset))	[2]




Example 1: OP1, Vset = 5V, Vadjust = 2V, I²C address = 20h, Voltage adjust register = F8h Use equation 2 to find the required data: 116.27*(1-(2/5)) = +70Set sign bit (Bit 8 =1 for positive numbers, 0 for negative numbers): +70 => 198 (C6h) Equation 1 will give the quantized setting: Vout = 5*(1-(70/116.27)) = 1.989VSend the following data over the I²C bus:

I ² C address	Register	Data
20h	F8h	C6h

Example 2: OP2, Vset = 6V, Vadjust = 12V, I²C address = 60h, Voltage adjust register = F8hUse equation 2 to find the required data: 116.27*(1-(12/6)) = -116Set sign bit (Bit 8 =1 for positive numbers, 0 for negative numbers): -116 => -116 (74h) Equation 1 will give the quantized setting: Vout = 6*(1-(-116/116.27)) = 11.986VSend the following data over the I²C bus:

I ² C address	Register	Data
60h	F8h	74h

Current control



Example 1:

Setup: OP1, Irated = 25A, Iadjust = 10A, I²C address = 20h, Current adjust register = F9h Use equation 2 to find the required data: 166.66*(10/25-0.711) = -52Set sign bit (Bit 8 =1 for positive numbers, 0 for negative numbers): -52 => -52 (34h) Equation 1 will give the quantized setting: lout = 25*(0.711+(-52/166.66)) = 9.974ASend the following data over the I²C bus: I²C address Register Data

I ² C address	Register	Data
20h	F9h	D7h

Example 2:

Setup: OP3, Irated = 7.5A, ladjust = 6A, l²C address = A0h, Current adjust register = F9h Use equation 2 to find the required data: 166.66*(6/7.5 - 0.711) = +15Set sign bit (Bit 8 =1 for positive numbers, 0 for negative numbers): +15 => 143 (8Fh) Equation 1 will give the quantized setting: lout = 7.5*(0.711+15/166.66) = 6.007ASend the following data over the l²C bus:

I²C addressRegisterDataA0hF9h8Fh